

## Bostik PU Foam Gun Plus

Ergonomic model for long-term usage



### Product Description

Long-lasting professional PU Foam gun.

### Benefits

- Easy to clean PTFE coated metal basket, nozzle and trigger to avoid the PU foam adhere
- Size and shape of the backscrew gives the feeling of better output control
- Ergonomic shape of the handle creates a good holding feeling
- Lightweight Plastic body supports the ergonomics of long working hours
- High quality gaskets for long service life

### Applications

Suitable for all Bostik manufactured PU Foams.

### Directions Of Use

Place the PU-foam can on a steady surface in an upright position and turn the PU-gun upside down. Place the basket of the PU-gun on top of the adaptor of the PU-foam can with the nozzle of the gun pointed away from your face position. Turn the PU-foam can and fasten the connection until you hear the pressure from canister floating into the gun. Tighten the connection with an extra twist. Turn the combination upside down and shake firmly at least 20 times. Summertime or Wintertime make sure the canister is always at room temperature 15 degrees. You can adjust the amount of PU-Foam flow from extruding the PU-foam by turning the screw knob at the end of the gun. Pre-wet the surface by spraying water. Pull the trigger of the PU-gun to start extruding the PU-foam. Ease the pull to extrude smaller beads. Continue extruding until the can is empty or when the job is finished. Place the combination on a steady surface in an upright position with the PU-gun pointed away from your face. Follow safety regulations of point 2. Unscrew the can and attach a new can to continue applying the PU-foam or remove it to start cleaning the PU-gun.

### Limitations

### Surface Preparations and Finishing

Not applicable.

### Paintability

Not applicable.

### Cleaning

Use a Universal PU Cleaner and attach the spray nozzle on the valve of the can. Spray directly onto the basket and nozzle of the PU-gun to remove all PU-foam residue. Remove the spray nozzle from the Universal PU Cleaner and screw the can on top of the PU-gun. Attach the additional plastic nozzle on the front of the PU-gun barrel. Pull the trigger and extrude all remaining PU-foam residue from the inside of the PU-gun till cleaner is coming out keeping the gun upside down. Place on a steady surface with the PU-gun pointed away from your face. Let the combination rest for 15 minutes so the cleaning solution can do its work in the interior of the PU-gun. Pull the trigger and spray the remaining cleaner from the interior of the PU-gun. All the pollution residue is now removed from the gun. Turn the combination upside down and place on a steady surface with the PU-gun pointed away from your face. Detach the Universal PU Cleaner and and extrude all Cleaner from the gun. Your PU-gun is now completely clean and can be reused over and over.

### Colour(s)

- Black

### Packaging

- Piece

*For product specifications, please refer to the Product Detail Page*

### Shelf Life

Not applicable.

### Health & Safety

Product Safety Data Sheet must be read and understood before use. These are available on request and via our websites

### Warranty & Guarantee

Bostik warrants that its product complies, within its shelf life, to its specification.

### Bostik Benelux B.V

Denariusstraat 11, 4903 RC Oosterhout, The Netherlands  
Phone: +31 (0)162491000, E-mail: [info@bostik.com](mailto:info@bostik.com)  
[www.bostik.com](http://www.bostik.com) | [www.denbraven.com](http://www.denbraven.com)

18-05-2024  
11:34:29  
CEST



## Bostik PU Foam Gun Plus

### Ergonomic model for long-term usage

#### Disclaimer

All information in this document and in all our other publications (including electronic ones) is based on our current knowledge and experience and is the exclusive (intellectual) property of Bostik. No part of this document may be copied, shown to third parties, reproduced, communicated to the public or used in any other way without Bostik written consent. The technical information in this document serves as an indication and is non-exhaustive. Bostik is not liable for any damage, either directly or indirectly, due to (editorial) errors, incompleteness and/or incorrectness of this document. This includes, but is not limited to, incompleteness and/or incorrectness due to technological changes or any research conducted between the date of publication of this document and the date on which the product is acquired. Bostik reserves the right to amend the wording of this document. Bostik be held liable for any damage, either directly or indirectly, due to the use of the product(s) depicted in this document. The user must read and understand the information in this document and other documents relating to the products prior to the use of the product. The user is responsible for performing all the requisite tests to make sure that the product is suitable for its intended use. We have no influence in what way the product is applied and/or any circumstances relating to events occurring during storage or transport and therefore we do not accept any liability for damage whatsoever. All deliveries are made exclusively in accordance with our general terms of conditions which have been filed at the Dutch Chamber of Commerce.

#### **Bostik Benelux B.V**

Denariusstraat 11, 4903 RC Oosterhout, The Netherlands  
Phone: +31 (0)162491000, E-mail: [info@bostik.com](mailto:info@bostik.com)  
[www.bostik.com](http://www.bostik.com) | [www.denbraven.com](http://www.denbraven.com)

18-05-2024  
11:34:29  
CEST